

ASSEMBLY INSTRUCTIONS

STEP 1

Insert Handlebar Stem Into Frame

*Cables should be in front of handlebar



ASSEMBLY INSTRUCTIONS

STEP 2

Tighten Stem Bolt



ASSEMBLY INSTRUCTIONS

STEP 3

Check & Ensure Four Bolts On Handlebar Are Tight



ASSEMBLY INSTRUCTIONS

STEP 4

Attach Wheels, Front & Rear

*Safety washer tab goes in small hole



STEP 5

Attach Front Brake

*Squeeze brake arms and insert the silver noodle into brake arm



FOR ADDITIONAL ASSISTANCE, Please contact us:

401 7th Street
Petaluma, CA 94952-4146
(707) 775-2452
info@diggler.com